## **Standard Operating Procedures Paint Prep**

Note: Follow paint company recommended procedures for new raw plastic bumpers.

## **Product List New Primed Bumper Prep** 3M™ Car Wash Soap Concentrate, Cleaning 1 gallon, PN 38377 Clean part with soap and water, followed by a VOC compliant surface cleaner. 3M™ All Purpose Cleaner and Degreaser Concentrate, 1 gallon, PN 38350 **Surface Prep Hand** Sand edges and other hard to reach areas 3M™ Flexible Abrasive using P400 flexible abrasive sheet until Hookit<sup>™</sup> Sheet, the surface is matte and all sheen has 5.5 in. x 6.8 in., P400, been removed. PN 34337 3M™ Flexible Abrasive Hookit<sup>™</sup> Foam Pad, **Surface Prep Machine** PN 34349 Sand remaining surfaces using P400 flexible abrasives on an orbital sander until the surface is matte and all sheen has been removed. 3M™ Orbital Sander, 10,000 RPM, PN 20331 3M™ Accuspray™ Spray Re-clean Gun Model HG14 Kit, Clean bumper surface with soap and 1.4mm, PN 16577 water, followed by a VOC compliant surface cleaner. Ear Plug, PN P1300 **Apply Top Coats** Seal and paint bumper following paint 3M™ Half Facepiece company recommendations. Respirator, PN 07182

## 3 in. x 4 in. Non-Vacuum,



Visit www.3MCollision.com for more SOPs and videos